

GABLE FALL SAFE ~ FALL ARREST SYSTEMS



Gable (UK) Ltd operate as part of the Approved Latchways Installer Network, with a bespoke specialist division, Gable Fall Safe, addressing the specific requirements associated with the design, installation and maintenance of Fall Arrest Systems. The Latchways System is cable based and provides continuous, hands-free safety at height or in areas of restricted access. The unique, patented TransFastner allows the user to move & work freely without the need to detach & reattach to the line and complies with all legislative requirements placed on employers with regards their Duty of Care.



The Fall Arrest system is an integral element of any site safety plan and the Latchways system is both versatile & flexible in its performance & capability.

Aesthetically, the system is incredibly discreet, with the simplicity of the components allowing them to be installed unobtrusively and on virtually any type of structure. The nature of its construction also means it offers a minimum of wind resistance and is durable enough to withstand the harshest of climatic conditions, be it in an industrial, commercial or other extreme environment.

Designed with a flexibility to operate horizontally, vertically, around corners or up & down inclines, the system offers total, uninterrupted worker protection, ensuring all legislative safety issues are fully addressed.



HEIGHT SAFETY LEGISLATION

The Health & Safety at Work Act 1974 puts a general onus on both employers & employees with respect to fall protection which must be afforded over 2m in height.

The Construction Health Safety & Welfare Regulations 1996 demands a Duty of Care in providing a safe place of work & means of access. All persons working above 2 metres, 2 metres from a fragile material or an exposed edge, must be suitably protected.

Construction, Design & Management Regulations 1994 (CDM) denotes a general requirement for designers to prepare for safe working practices both during & post construction.

Management of Health & Safety at Work Regulations 1992 requires employers to make suitable risk assessment for the health & safety of all employees whilst at work and identify the measures to be taken to comply with relevant statutory duties.

Personal Protective Equipment at work Regulations 1992 (enforced 1995) lays down guidelines on the provision of PPE, its maintenance, replacement and training requirements.

European Directive 086/89/EFC requires all personnel working in unprotected areas with a possible fall in excess of 2m to wear fall arrest equipment